



MODULE TO MUTE THE MICROPHONE 260 PROCESSING MODULE 232

MODULE TO
CONNECT THE
MICROPHONE TO
THE VOICE INPUT
PROCESSOR OF THE
MOBILE TERMINAL
WHEN A CALL IS
CONNECTED
261

**MEMORY 248** 

PHONE DIRECTORY 240

VOICE RECOGNITION MODULE 246

SYNCHRONIZATION PROGRAM 244

MODULE TO
CONNECT THE
PREAMPLIFIER
OUTPUT OF THE
STEREO TO THE
AUDIO INPUT OF
THE AUDIO
OUTPUT SYSTEM
WHEN A CALL IS
NOT CONNECTED
OR BEING SETUP
262

MODULE TO
CONNECT THE
EARPIECE
AMPLIFIER
OUTPUT OF THE
MOBILE TERMINAL
TO THE AUDIO
INPUT OF THE
AUDIO OUTPUT
SYSTEM WHEN A
CALL IS
CONNECTED
264

MODULE TO STORE TELEPHONE NUMBERS AND ASSOCIATE THEM WITH SPOKEN TOKENS 266

MODULE TO
CONNECT THE
PREAMPLIFIER
OUTPUT OF THE
MICROPHONE TO
THE PROCESSING
MODULE WHEN A
CALL IS BEING
SETUP
263

MODULE TO PROMPT A USER TO PROVIDE PHONE NUMBERS TO DIAL 267

FIG. 2B





